

SAFETY DIRECTIONS

Please read this information using this product. Please keep this user manual for further reference.

1. The manufacturer does not accept any responsibility for injuries or damage resulting from improper use of the product. If in doubt, consult a qualified electrician.
2. Do not place the product on a damp or conductive subsurface.
3. Place 2 C batteries into the battery case
4. Maintenance/cleaning of the lights is limited to the surface exterior, using a dry cloth only.
5. The internal LED chain can't be replaced. If the lamp is defective, please return this to a point of acceptance for the recycling of electric and electronic devices. Please ask your local municipality for the nearest point of acceptance.

HOW TO OPERATE THE CANDLE AND TIMER“ ON/OFF MODE”

1. Put the switch in the ON position to turn the candle on.
2. To turn the candle off, put the switch in the OFF position.

“TIMER” MODE

1. To set the 5-hours timer, put the switch in the TIMER position.
2. The following day, if the settings have not been modified, the candle will automatically turn on at the same time and will turn off after 5 hours
3. To change the starting time, put the switch in the OFF position and back to TIMER position.
4. To deactivate the “TIMER”, put the switch in the OFF position.

