
you an ecological-friendly product of superior quality. Please read this instruction carefully before use.

Initial charging:

If the solar panel is covered with a thin protective film, remove it before using the product. Remove the solar puck by aligning the arrows on the solar panel and basket and then lifting the solar panel. Remove the solar puck and set the switch to the "ON" position. The basket may need to be turned upside down to allow the solar puck to fall out. Place solar puck on top of the PVC basket, align the arrows on the solar panel and basket and turn clockwise to lock into place. Place the solar light in a location where it can receive a full 8 hours of sunlight to allow the rechargeable batteries to reach maximum capacity. The switch can be left in the "ON" position and the light will turn on automatically at dusk.



Charging Direction:

Place the solar light fixture in an area where it can receive direct sunlight for at least 8 hours each day. Shadowed locations will not allow the battery to charge fully and will reduce the hours of nighttime lighting. The selected location should not be near nighttime light sources, such as porch lights, street lights or pool lights, as these may cause the solar light to turn off prematurely.

Battery Replacement:

NOTE: This operation should be done in the morning on a sunny day. This will allow the lantern to receive a full 8 hours of sunlight so that the rechargeable battery can reach maximum capacity.

- Remove the solar puck by aligning the arrows on the solar panel and basket. The basket may need to be turned upside down to allow the solar puck to fall down.
- Remove the 4 screws that hold the battery cover.
- Remove the old battery and replace with new AA size 1.2V rechargeable batteries of same or greater capacity (mAh).
 (USE RECHARGEABLE BATTERIES ONLY).

Note: Clean the battery contacts and those of the device prior to battery installation.

- Be sure to insert the battery in proper direction .
- Replace the battery cover on the solar puck using the 4 screws.
- Replace the solar puck by turning it clockwise.

ON/OFF Switch Solar Puck Screws

Warning:

- Safe for outdoor operation.
- Failure to insert battery in the correct polarity, as indicated in the battery compartment, may shorten the life of the battery or cause battery to explode or leak.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of as per manufacturer's recommendations.
- Remove battery if consumed or if product is to be left unused for a long period.
- REPLACEMENT PARTS MAY BE ORDERED BY USING THE FIXTURE MODEL NUMBER AND THE PART'S NAME.

Care and Cleaning:

Solar panel should be cleaned periodically with damp cloth for maintaining optimum performance (to remove dust and debris). Do not place in areas where children normally play, or where they may trip and fall against the solar lantern.

ONE (1) YEAR LIMITED WARRANTY

This product is guaranteed to be free from defects in material and workmanship for one (1) year following the date of purchase (excluding the battery/batteries). Should a defect occur within the warranty period, please contact our customer service line at 1-888-867-6095 or at the following email address: customerservice@niinorthern.com. A proof of purchase (sales receipt) will be required. If we cannot replace the defective part you require, you can return your product to the original point of purchase for a full refund or a replacement product. The consumer is responsible for the removal of and reinstallation of the product. Damage to any parts as such by accident, misuse, or improper installation is NOT covered by this warranty. Our policy does not include liability for incidental or consequential damages. Some states or provinces do not allow the exclusion or limitation of consequential damages; therefore, the above exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights that vary from place to place.

Patented Technology U.S. Pat. 7,093,961 Other patents pending.